RIKI Pore Cleanser

User Manual



RIKI LOVES RIKI

1 Instruction

RIKI Pore Cleanser is a must-have for any beauty routine. Crafted from durable stainless steel,RIKI Pore Cleanser offers three vibration modes to target stubborn blackheads, reveal instant glow, or gently exfoliate daily buildup

2 In the Box



RIKI Pore Cleanser | Charging Cable | Instruction Manual

3 Product Description



4 Safety Information

Important: Improper use of this device may result in injury or damage.

1. Use with care to avoid burns or injuries.
2. Always switch off the device immediately after use and before cleaning to prevent damage.
3. This product is not suitable for individuals with physical, sensory, or cognitive disabilities, or those lacking experience or knowledge (including children), unless supervised by a responsible adult.
4. This device is not water-resistant—do not immerse it in water.
5. The device charges via a 5V USB port, with a full charge taking about 50 minutes.
6. Keep the device away from high temperatures and humid environments to avoid damage.
7. Avoid dropping or hitting the device, as it may cause operational issues.
8. During operation, the device may emit a faint, high-pitched tone caused by its operating frequency being close to the audible range. This is a normal characteristic and does not indicate any malfunction.
9. Store the device out of reach of children.
10. If the device malfunctions, stop using it immediately and contact customer support. If you experience discomfort or pain during use, stop immediately and consult a healthcare professional. This product is not recommended for individuals with skin conditions such as dermatitis, eczema, or swelling.

Heads-up:

Do not use on the following persons:

1. Patients with pacemakers or severe heart rhythm disorders

5 Safety Information

2. Individuals with cognitive impairments or skin sensory paralysis
3. Infants, pregnant women, and women within 60 days postpartum

Do not use on the following body areas:

1. Areas with metal or plastic implants
2. Skin with open ulcers or wounds
3. The heart, both sides of the carotid artery, the front of the head, and the throat

6 Charging

Connect the device to the charging cable and adapter, then plug it into a household power outlet. While charging, the LED indicator will flash. Once fully charged, the LED indicator will stop flashing. The device cannot be powered on while charging.

7 Functional Modes - How to Use

Mode 1: Clease

1. Press and hold the Power Button for two(2) seconds to power on the RIKI S
2. Start by cleansing your face with a facial wash.
3. Enhance results by applying warm compresses and a blackhead-extraction solution. Spritz a small amount of water or toner onto your skin.
4. Hold the device so the blade faces inward at a 45° angle.The metal plate on the back should rest against your palm.

8 Functional Modes - How to Use

5. Glide the blade slowly along your facial contours to lift away any remaining impurities.



Mode 2: Infuse

1. Press and hold the Power Button for two(2)seconds to power on the RIKI SCULPTOR.
   Single press the M button to enter Mode 2
2. Cleanse your face with a facial wash first. Apply a mask or lotion-based skincare product.
3. Hold the device so the blade faces outward at a 45 angle to your skin,the front button should point toward your palm.
4. Glide the blade slowly along your facial contours to boost absorption of the skincare formula.



9 Functional Modes - How to Use

Mode 3: Lift

1. Press and hold the Power Button for two(2)seconds to power on the RIKI SCULPTOR.
   Single press the M button twice to enter Mode 2
2. Cleanse your face with a facial wash. Apply a serum or other skincare product.
3. Hold the device so the blade faces outward at a 45 angle to your skin; the front button should point toward your palm.
4. Glide the blade slowly along your facial contours to enhance absorption and provide a gentle lifting effect.



10 Product Specifications

Product Name	RIKI Pore Cleanser
Charging Voltage	5V
Charging Current	1A
Charging Method	USB Charging
Product Weight	83g
Materials	ABS+Stainless Steel +Silicon
Battery Capacity	350mAh
Waterproof Rating	IPX0
Product Size	7.09 × 1.69 × 0.68 inches (180 × 43 × 17.3 mm)

⚠ WARNING: FOR INDOOR USE ONLY

This device complies with Part 15 of the FCC Rules. Operation is subject to thefollowing two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency, energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the used is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antanna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that towhich the received in connected.
-Consult the dealer or an experienced radio TV technician for help.

CE FC

RIKI LOVES RIKI™ and RIKI LOVES RIKI™ are trademarks of GLAMCOR GLOBAL LLC.

GLAMCOR GLOBAL LLC
99 Wall Street, 3103
New York, NY 10005

www.rikilovesriki.com
Customer Service: realperson@glamcor.com

©2026 All rights reserved.
Made in China

RIKI LOVES RIKI™