RIKI STYLER

User Manual



RIKI LOVES RIKI

1 Instruction

RIKI Styler combines a hot comb and flat iron into one palm sized tool. Its adorable and compact design effortlessly creates straight hair. With four adjustable heat settings, it offers personalized styling for various hair types. The 360° anti scald protection ensures safe and comfortable use. Built in negative ion technology helps to reduce frizz and enhance shine, leaving your hair smooth and vibrant.

2 Inside the Box



RIKI STYLER | Charging Cable | Instruction Manual

3 Product Description



Attention

4 Instruction

Important: Improper use of this device may result in injury or damage.

1. Use with care to avoid burns or injuries.
2. Always switch off the device immediately after use and before cleaning to prevent damage.
3. This product is not suitable for individuals with physical, sensory, or cognitive disabilities, or those lacking experience or knowledge (including children), unless supervised by a responsible adult.
4. This device is not water-resistant—do not immerse it in water.
5. The device charges via a 5V USB port, with a full charge taking about 30 minutes.
6. Keep the device away from high temperatures and humid environments to avoid damage.
7. Avoid dropping or hitting the device, as it may cause operational issues.
8. Store the device out of reach of children.
9. If the device malfunctions, stop using it immediately and contact customer support. If you experience discomfort or pain during use, stop immediately and consult a healthcare professional.

Heads-up:

1. Start with the lowest heat setting and gradually increase if necessary. Fine or chemically treated hair requires lower temperatures.
2. Section your hair for easier and more effective styling.
3. Gently glide the comb through small sections of hair from root to tip. Do not hold the comb in one place for an extended period.
4. Avoid direct contact with the scalp to prevent irritation or burns.Never leave the powered-on device unattended.
5. The plates and comb teeth will be extremely hot during and after use. Avoid touching these surfaces.

5 Instruction

6. Keep the device away from water and other liquids. Do not use it with wet hair or near a bathtub, sink, or shower.
7. Do not use on hair with extensions without first consulting a professional stylist.

6 Charging

Connect the device to the charging cable and adapter, then plug it into a household power outlet.
Charging: Red light blinks.
Fully charged: Blue light is solid.
The device cannot be powered on while charging.

7 Functional Modes - How to Use

1. Press and hold the Power Button for two(2)seconds to power on/off the RIKI Styler
2. Briefly press the power button to cycle through the four heat settings. The LED indicator will change color to show the active mode. The negative ion function is automatically activated whenever the device is powered on, helping to reduce frizz and enhance shine at any temperature setting.

① Press: Red Light - 248°F (120°C)
(For fine or delicate hair)



8 Functional Modes - How to Use

② **Presses**: Blue Light - 284°F (140°C)
(For normal or medium-texture hair)



③ **Presses**: Green Light - 320°F (160°C)
(For thick or wavy hair)



④ **Presses**: Purple Light - 356°F (180°C)
(For very thick or coarse hair)



The device will remember your selected temperature until you change it or turn the unit off.The RIKI STYLER will automatically power off after 10 minutes.

9 Product Specifications

Product Name	RIKI STYLER
Charging Voltage	5V
Charging Current	2A
Charging Method	USB Charging
Product Weight	141g未确认
Materials	AB +PC+stainless steel+silicon
Battery Capacity	2000 mAh
Waterproof Rating	IPX0
Product Size	74.41 × 3.41 × 1.27 inches (112X86.5X32.2mm)

ABS+PC+Silicon+Stainless steel

ABS+PC+Silicon+Stainless steel

⚠ WARNING: FOR INDOOR USE ONLY

This device complies with Part 15 of the FCC Rules. Operation is subject to thefollowing two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency, energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipmentt does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the used is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antanna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that towhich the received in connected.
-Consult the dealer or an experienced radio TV technician for help.

CE FC

RIKI LOVES RIKI™ and RIKI LOVES RIKI™ are trademarks of GLAMCOR GLOBAL LLC.

GLAMCOR GLOBAL LLC
99 Wall Street, 3103
New York, NY 10005

www.rikilovesriki.com
Customer Service: readperson@glamcos.com

©2026 All rights reserved.
Made in China

RIKI LOVES RIKI