RIKI SCULPTRESS

User Manual



RIKI

1 Instructions

The RIKI SCULPTRESS tool combines several advanced skincare functions into one device, including heat therapy, vibration, cooling, EMS, LED light therapy, and gua sha. Its ergonomic design delivers a consistent, soothing massage with adjustable cooling or heating modes for ultimate relaxation. In addition to its massage capabilities, it can be used for gua sha treatments and targeted muscle relief, helping to ease tension and promote relaxation.

2 Inside the Box



RIKI SCULPTRESS




Charging Cable



Instruction Manual

3 Product Description



4 Safety Information

Important: Improper use of this device may result in injury or damage.

1. Use with care to avoid burns or injuries.
2. Always switch off the device immediately after use and before cleaning to prevent damage.
3. This product is not suitable for individuals with physical, sensory, or cognitive disabilities, or those lacking experience or knowledge (including children), unless supervised by a responsible adult.
4. This device is not water-resistant—do not immerse it in water.
5. The device charges via a 5V USB port, with a full charge taking about 1.5 hours.
6. Keep the device away from high temperatures and humid environments to avoid damage.
7. Avoid dropping or hitting the device, as it may cause operational issues.
8. Store the device out of reach of children.
9. If the device malfunctions, stop using it immediately and contact customer support. If you experience discomfort or pain during use, stop immediately and consult a healthcare professional. This product is not recommended for individuals with skin conditions such as dermatitis, eczema, or swelling.


5 Charging

While charging, the Power Button will blink red light continuously. Once charging is complete, the red light will stop blinking.

Note: The RIKI SCULPTRESS cannot be used while it is charging.

Functional Modes - How to Use

Mode 1: Therapeutic Warmth + Red LED Light



1. Press and hold the power button ⏻ for two (2) seconds to power on the RIKI SCULPTRESS.
2. The Power Button ⏻ will display a red light indicating **Mode 1**.

Single press the Power Button to change intensity levels (Low/Medium/High):

- Low: ⏻ Power button is a steady red light.
- Medium: ⏻ Power button is a slow blink red light.
- High: ⏻ Power button is a fast blinking red light.

Vibration mode: Press and hold the M Ⓜ button.
Switch between modes: Single press the M Ⓜ button.
Note:

- The RIKI SCULPTRESS will automatically power down after 10 minutes.

Mode 2: Cooling + Blue LED Light



1. Press and hold the power button ⏻ for two (2) seconds to turn on the RIKI SCULPTRESS.
2. Single press the M button Ⓜ to enter Mode 2.
3. The Power Button ⏻ will display a blue light, indicating **Mode 2**.

Single press the Power Button ⏻ to change intensity levels (Low/Medium/High):

- Low: ⏻ Power Button is a steady blue light.
- Medium: ⏻ Power Button is a slow blink blue light.
- High: ⏻ Power Button is a fast blink blue light.

Vibration mode: Press and hold the M Ⓜ button.
Switch between modes: Single press the M Ⓜ button.

Note:
- The RIKI SCULPTRESS will automatically power down after five (5) minutes in **Mode 2**.
- After turning off the RIKI SCULPTRESS in **Mode 2**, the cooling fan may run for about 30 seconds. This is normal and will stop automatically once cool.

Mode 3: Electrical Muscle Stimulation + Purple LED Light



1. Press and hold the power button ⏻ for two (2) seconds to turn on the RIKI SCULPTRESS.
2. Press the M button Ⓜ twice to enter **Mode 3**.
3. The Power Button ⏻ will display a purple light, indicating Mode 3.

Single press the Power Button ⏻ to change intensity levels (low/medium/high):

- Low: ⏻ Power Button is a steady purple light.
- Medium: ⏻ Power Button is a slow blink purple light.
- High: ⏻ Power Button is a fast blink purple light.

Vibration mode: Press and hold the M Ⓜ button.
Switch between modes: Single press the M Ⓜ button.

Note:
- The RIKI SCULPTRESS will automatically power down after five (5) minutes in **Mode 3**.
- After turning off the RIKI SCULPTRESS in **Mode 3**, the cooling fan may run for about 30 seconds. This is normal and will stop automatically once cool.

Facial Massage Technique



V-Face Lift:
Lift the height of the cheek muscles from the side of the chin upwards along the jawline.



Reduce the appearance of lines:
Lift from the lateral end of the nose or the corner of the mouth along the outer contour of the cheekbone to the earlobe.




Reducing forehead wrinkles:
Start from above the eyebrows and lift from the brows to the hairline.




Eliminate eye bags:
Start from below the corner of the eye, and follow the curve of the outer eye to the temple.

10 Gua Sha Body Techniques


Gua Sha Pushing & Scraping:



Back



Leg



Hand

11 Daily Care for Skin Success



1. Cleanser



2. Lotion/Oil



3. Hot Lift



4. Face Mask

12 Product Specifications

Product Name	RIKI SCULPTRESS
Charging Voltage	5V
Charging Current	1A
Charging Method	USB Charging
Product Weight	132g
Materials	ABS+PC+Zinc Alloy+Silicon
Battery Capacity	800mAh
Waterproof Rating	IPX0
Product Size	3.7*3.5*1.44 in (95*89*34mm)

RIKI LOVES RIKI™ and RIKI ♡ IKIR™ are trademarks of GLAMCOR GLOBAL LLC.

GLAMCOR GLOBAL LLC
99 Wall Street, 3103
New York, NY 10005

www.rikilovesriki.com

Customer Service: realperson@glamcor.com

©2025 All rights reserved.
Made in China

⚠ WARNING: FOR INDOOR USE ONLY

This device complies with Part 15 of the FCC Rules. Operation is subject to thefollowing two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency, energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipmentt does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the used is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antanna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that towhich the received in connected.
-Consult the dealer or an experienced radio TV technician for help.