RIKI EYELASH CURLER



1 Tips

Be sure to retain the instruction manual for future reference after you have finished reading it. If you plan to pass the product along to someone else, it is important to include the instruction manual with it. The images, features, and terminology provided in the instruction manual serve as a guide. For accurate information, refer to the actual product when using it.

2 Safety Information

This instruction manual outlines essential safety precautions to ensure the protection of users and others from personal injury and property damage. It is crucial to read and comprehend this manual in its entirety before operating the product and to adhere to the instructions provided for responsible use.

Caution: Misuse of this product can lead to personal injury or property damage.

1. Exercise caution when in use to prevent burns or injuries around the eye area.

2. Ensure to switch off the power immediately after use and during cleaning to safeguard the device from damage.

3. This device is intended solely for application on eyelashes; refrain from using it on other body parts.

4. As this product is not water-resistant, do not immerse it in water.

5. This item is charged through a 5V USB port, with a typical charging time of approximately 1.5 hours for a full charge.

6. Keep the product away from high-temperature and high-humidity environments to avoid damage.


7. Refrain from dropping or striking the product, as this may result in operational issues.

8. Ensure this product is stored out of reach of children.

3 What's inside the box?



RIKI EYELASH CURLER *1



Charging Cable *1




Instruction Manual *1

Product Information

Product Name	RIKI EYELASH CURLER
Charging Voltage	5V
Charging Current	350 mA
Charging Method	USB Charging
Host Weight	0.07lb (33g)
Temperature Range	60-80℃ (4.2V)
Battery Capacity	350mAh
Working Current	170mA-210mA (4.2V)
Product Size	0.708 *0.79*0.59in (1.8*2*1.5cm)

Product Description



1. Temperature sensor
2. Open/close tongs
3. ON/OFF button
4. Temperature indicator
5. Charging port

5 Method of Application

1. To turn on the device, press and hold the button for 2 seconds. Click the ON/OFF button to set the desired working temperature:

- The first setting (blue light) corresponds to a temperature of 60°C (140°F)
- The second setting (red-and-blue flashing light) is for a temperature of 70°C(158°F) .
- The third setting (red flashing light) indicates a temperature of 80°C(176°F).

2. After about 20 seconds, the temperature sensor will shift from purple to pink.

3. For optimal results, it is recommended to apply a layer of mascara prior to using the device.

4. Instructions for using the device:

A. To style and shape your eyelashes with the heated comb:

- Press the heated comb against the base of your eyelashes for a few seconds. The stiffer your eyelashes are, the more time it will take to achieve the desired shape.

B. To curl your eyelashes using the eyelash styling clip:

- Turn on the RIKI EYELASH CURLER.
- Secure your natural or false eyelashes with the styling clip.
- Maintain the position for 3 seconds, then release. For a more pronounced curl, gently bend your wrist upwards while holding the eyelashes.

Attention

Environmental Protection Product hosts, packaging and accessories are made from recyclable materials. Sorting and recycling wasteproducts can help reuse materials.

Waste Disposal

If there is such a mark on the product, instruction manual or pack x 10.52 mm is reminded that this produ 3202 mm ot be treated as general household waste at theend of itsservice life.Please recycle it according to the classification of the waste.







⚠ Note
In view of the consistent policy of continuous product improvement, the company reserves the right to change product specifications without notice.

⚠ WARNING: FOR INDOOR USE ONLY

This device complies with Part 15 of the FCC Rules. Operation is subject to thefollowing two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency, energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipmentt does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the used is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antanna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that towhich the received in connected.
-Consult the dealer or an experienced radio TV technician for help.

CE | FC