Universal Flat Base Stand




Quick Start Guide


US and foreign Patent(s) Pending

Identifying the kit components


This stand is compatible with the Reveal, Elite X, Revolution X, Ultra X, Multimedia X, and the Horizon



Adjustable stand



Acrylic flat base




Flat base nut

01 Preparing your stand for use

A Unscrew the Base Nut:

Find the nut on the rear end of the stand.
Gently unscrew it.




B Attach the Nut:

Put the nut on the back of the Acrylic base,
matching the hole.



02 Preparing your stand for use





C Connect Stand and Nut:

On the front side of the Acrylic base, align the stand with the nut.
Turn the stand clockwise to screw it into the Acrylic base.
Make sure it's tightly attached.

03 Preparing your stand for use

D **Adjust the Slider:**
Loosen the knob on the stand to adjust the slider's height.







E **Lock the Slider:**
Tighten the knob clockwise after adjusting the height.

04 Preparing your stand for use

F Adjust the Height of Top Pole:
Ensure that the top pole's height is at least 3 inches (7.5 cm) above the knob.




This prevents contact between the power plug on the bottom of the light and the knob, reducing the risk of damage.



Note: Failing to follow this instruction can lead to breaking the power plug on the bottom of the light if contact is made with the knob.

05 Mount your luminary onto the flat base stand



06 Secure luminary by tightening knob



Warranty / Guarantee

IMPORTANT

Thank you for purchasing this product. It has been made to demanding high-quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please contact GLAMCOR by email (realperson@glamcor.com) or return it to the place of purchase.

Normal wear and tear is not covered under the guarantee. Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service center.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

After Sales Customer Service Department:
GLAMCOR
110 Wall Street Floor 5
New York, NY 10005
EMAIL: realperson@glamcor.com

Please retain for future reference. Colors and contents may vary.

Recycling

DISPOSAL

The packaging material is recyclable. Dispose of the packaging in an environmentally friendly manner, and make it available for the recyclable material collection service.

Dispose of the product in an environmentally friendly manner when you decide to part with it. This device should not be disposed of with household waste. Dispose of it at a recycling center for old electrical and electronic appliances.

Please recycle where facilities exist.

Check with your Local Authority or retailer for recycling advice.

© 2023 GLAMCOR GLOBAL LLC. Reproduction in whole or in part without written permission is prohibited. All rights reserved. GLAMCOR is a trademark of GLAMCOR GLOBAL LLC.